

## Field Service Information 2023.04

Our Ref Erik Helldin Date

April 4th, 2023

## Ground Connection on Jetting Machines with connected JetLogger

Electronics in general are sensitive to ESD, electrostatic discharge. Jetting notice that ESD / static interference is common in certain circumstances where optical fibre cables are installed. This is depending on air temperature, humidity, environment, type of optical fibre cable, cable drum with setup and type of duct. Lubing the duct normally decreases the level of ESD as well. In some cases grounding comes natural. Where this is not the case we recommend to attach a grounding cable between machine and cable/duct cabinet. In some cases, a cable between the machine and the cable drum is also necessary.


Below some examples where to attach the cable on the Jetting machines.

Ground cable



Ground point V0-series: Screw knob for cable guide fixation.

follow us on in ና



Jetting AB Murgatan 1 SE-522 30 Tidaholm Sweden Telephone +46 502 65 90 10





Best regards

Erik Helldin

Regional Sales Manager Quality Coordinator



Tel: +46 763 12 73 51

erik@jetting.se



Follow Jetting on LinkedIn & Facebook!



follow us on in ና