



# IDEAL AnyAWARE™

## Quick Connect Application Note

1.



Edimax EW-7811UN



LanTEKIII, SignalTEKII/NT/CT, NaviTEKII/NT

2.

SSID & : Default: SSID: IDEAL[SN]..... : ideal001606

3.




ON

a. LanTEKIII :  
[ON] → [SHIFT] + [F2]

b. SignalTEKII /CT/NT , NaviTEKII/NT  
[ON] → JOB

4.



5. START

